



(CZ) Výška dveří / (SK) Výška dverí / (PL) Wysokość drzwi / (DE) Türhöhe

1737 mm: 6132151, 6132156, 6132161, 6132166, 6132171, 6132176, 6132181, 6132186, 6132191

2087 mm: 6132153, 6132158, 6132163, 6132168, 6132173, 6132178, 6132183, 6132188, 6132193




1

(CZ) Součástky **K** a **O** namontujte na korpus Vaší skříně a dále pokračujte v montáži dveří dle návodu.


(SK) Súčiastky **K** a **O** namontujte na korpus Vašej skrine a dále pokračujte v montáži dveří dle návodu.


(PL) Zamontuj elementy **K** i **O** na korpusie szafki i kontynuuj montaż drzwi zgodnie z instrukcją.

(DE) Montieren Sie die Bauteile **K** und **O** am Korpus Ihres Schrankes und fahren Sie mit der Montage der Tür gemäß der Anleitung fort.




J	K	L	M	N	O	P
8×	8×	20×	2×	1×	1×	2×
		Ø 3,5 x 16				





3

1



2

